



Operating Instructions for EcoTemp Thermometer

INSTRUMENT OPERATION

The instrument is switched on by pressing the on/off button located on the front of the instrument. Within one second the thermometer is ready to work. Apply the tip of the probe to the substance or medium to be measured. The instrument reading may take a few seconds to stabilise, depending on the nature of the measurement.

MAX/MIN MEMORY FUNCTION

Press the MAX/MIN button to display the maximum reading and a MAX symbol will flash in the display. Press the MAX/MIN button again to display the minimum reading and a MIN symbol will flash in the display. Press MAX/MIN button again to return to the normal reading. To clear the MAX/MIN temperature memory, press the MAX/MIN and ON/OFF buttons simultaneously.

BATTERY REPLACEMENT

Replace the batteries immediately the "Bat" illuminates or if the reading becomes erratic or the display clarity fades, using two AAA, MN2400 or 1.5 volt equivalent. The batteries are located under the battery cover at the rear of the instrument.

EMC/RFI

Instrument readings may be affected if the unit is operated within a radio frequency electromagnetic field strength of approximately 3 volts per metre.

OPTIONS

ETI Order Code 810-951	Replacement Penetration Probe
ETI Order Code 810-952	Optional Wire Probe
ETI Order Code 830-215	Optional Protective Rubber Boot

PRODUCT WARRANTY & GUARANTEE

This instrument carries a one-year warranty and guarantee against defects in either components or workmanship. During this period, products that prove to be defective will, at the discretion of ETI Ltd, be either repaired or replaced without charge. This warranty does not apply to probes, where a six-month period is offered. The product warranty and guarantee does not cover damage caused by fair wear and tear, abnormal storage conditions, incorrect use, accidental misuse, abuse, neglect, misapplication or modification, or use with non-ETI Ltd hardware/software. No warranty of fitness for a particular purpose is offered and the user assumes the entire risk of using the product. Any liability by ETI Ltd is limited only to the replacement of defective materials or workmanship, and ETI Ltd accepts no responsibility for consequential loss. In line with our policy of continuous development, we reserve the right to amend our product specification without prior notice.



Supplied by

Electronic Temperature Instruments Ltd

Dominion Way · Worthing · West Sussex · BN14 8NW

Telephone: (01903) 202151 · Facsimile: (01903) 202445

E-mail: sales@etiltd.co.uk · www.etiltd.co.uk